

Picture #23 – JST SM Battery Connections



30. Route the two DPDT switches and their wire connections through the boiler body and out the front of the standard “Big Hauler” chassis and install them in the smoke box door using 1-72 x 3/16” screws (refer to photo #24).