

- 27. Connect the center leads from second DPDT switch (this switch will allow you to select track or battery power) to the Revolution power inputs on the Blue Tom board (refer to Figure #2).
- 28. Solder one end of the second DPDT switch to the track power leads of the Anniversary chassis (refer to Figure #2). Remember to use heat shrink tubing to protect the solder connections.
- 29. Solder the other end of the second DPDT switch to a male JST SM connection routed out the back of the "Big Hauler" body (refer to Figure #23). Remember to use heat shrink tubing to protect the solder connections.